

INDIANA DEPARTMENT OF TRANSPORTATION
MATERIALS AND TESTS DIVISION

PERMEABILITY OF AGGREGATES
ITM No. 208-00T

1. SCOPE

1.1 This test method is used to determine the coefficient of permeability of an aggregate sieve under a constant head.

1.2 The values stated in either SI metric or acceptable English units are to be regarded separately as standard, as appropriate for a specification with which this ITM is used. Within the text, English units are shown in parenthesis. The values stated in each system may not be exact equivalents; therefore each system shall be used independently of the other, without combining values in any way.

1.2 This ITM may involve hazardous materials, operations, and equipment. This ITM does not purport to address all of the safety problems associated with the ITMs use. The ITM user's responsibility is to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

2. SIGNIFICANCE AND USE

2.1 This ITM is used to measure the rate of flow of water through an aggregate.

2.2 This test is valid for aggregates with a top size of 38 mm or smaller that contains less than 20% passing the 75um sieve.

2.3 This test is more accurate under conditions of laminar flow. A permeability constant of less than 0.001 m/sec indicates laminar flow is more likely. A permeability constant greater than 0.001 m/sec indicates that laminar flow is less likely.

3. REFERENCES

3.1 AASHTO

M92 Standard Specification for Wire Cloth and Sieves for Testing Purposes
T87 Dry Preparation of Disturbed Soil and Soil Aggregate Samples for Test
T248 Reducing Field Samples of Aggregate to Testing Size
T265 Laboratory Determination of Moisture Content of Soils

3.1 ITM

ITM 207 Sampling Stockpiled Aggregates

4. TERMINOLOGY

4.1 Terms and Abbreviations. Definitions for terms and abbreviations will be in accordance with the Department's Standard Specifications, Section 101.

5. APPARATUS

5.1 Permeameter. An apparatus used to determine the permeability of an aggregate. The permeameter includes the reservoir assembly, mold, locking ring, tubes and drain pan.

5.2 Reservoir Assembly. That portion of the permeameter used to provide and regulate a flow of water through an aggregate sample. The reservoir assembly includes the reservoir, pipe, hoses, and lid.

5.3 Reservoir. A cylindrical vessel having an open top, one inlet, two outlets a minimum height of 250 mm and minimum diameter of 250 mm. The inlet shall have an inside diameter of 15 mm and be located 216 mm above the base. The overflow outlet shall have a 15 mm inside diameter and be located 63 mm above the base. The base outlet shall have an inside diameter of 21 mm and be located in the center of the base to accommodate the pipe.

5.4 Pipe. The pipe connects the lid to the reservoir. The pipe shall have a 21 mm inside diameter. The pipe shall be long enough to provide 300 mm distance between the bottom of the lid and the middle of the overflow outlet in the reservoir.

5.5 Hoses. Flexible tubing 1.0 - 1.5 m long with an inside diameter of 17 mm. The inlet hose shall be used to connect the water source to the reservoir inlet. The outlet hose shall be used to connect the overflow outlet to the drain.

5.6 Lid. The lid covers the top of the mold. The lid shall have a gasket to provide a watertight seal, a valve to allow the escape of trapped air, and an inlet in the center to accommodate the pipe.

5.7 Mold. A cylindrical vessel having a rounded bottom, open top, one outlet, two manometer connections, a height of approximately 218 mm and inside diameter of approximately 204 mm. The mold outlet shall have an inside diameter of 19 mm and be located in the center of the base. The lower manometer connection shall be located 152 mm below the top of the mold. The upper manometer connection shall be located 25 mm below the top of the mold.

5.8 Locking Ring. A metal ring with bolt used to secure the lid to the mold to make a watertight seal.

5.9 Tubes. Two flexible clear plastic tubes, at least 1 m long, which affix to the manometer connections and display the head of water at each manometer connection.

5.10 Drain Pan. A shallow cylindrical vessel at least 300 mm in diameter and 125 mm deep having an outlet with an inside diameter of 25 mm near the top. The drain pan is placed under the permeameter to collect the water flowing out of the mold and to provide a constant depth of water.

5.11 Bottom Screen. A square piece of test grade woven wire cloth with an average opening of 9.5 mm approximately 40 mm square in accordance with M 92.

5.12 Top Screen. A piece of test grade woven wire cloth with an average opening of 4.75 mm approximately 200 mm in diameter in accordance with M 92. The top screen will fit closely within the mold to prevent the loss of fines.

5.13 Laboratory Gravel. A washed, well rounded, uncrushed, uniform graded gravel with 100% passing the 12.5 mm sieve and 100% retained on the 9.5 mm sieve. The quantity of material shall be sufficient to provide a firm, well draining, level foundation to support the top screen at the height of the lower manometer connection.

5.14 Vibrating Table. A table, with moveable top, that vibrates to help compact the specimen inside the mold.

5.15 Card board Cover. A round waterproof piece of cardboard that fits tightly inside the mold and is used to contain the specimen during compaction.

5.16 Compaction Weight. A round 9 kg weight that fits inside the mold and is used to compact the specimen.

5.17 Spacers. Shims of various thickness used in the drain pan to control the height of the mold so that the bottom of the specimen is at the same elevation as the water.

5.18 Bracket. A vertical steel rod with a heavy flat base and adjustable clamps to hold the manometer tubes in a vertical position.

5.20 Deflector. A strip of stiff material 30 ± 10 mm wide placed in the reservoir to intercept and disperse the flow of water and prevent a vortex in the reservoir.

5.21 Collection Bucket. A 20 liter container that sits in the sink and is used to collect the flow of water out of the drain pan for 60 seconds.

5.22 Miscellaneous lab equipment. Includes clock, scoop, rubber stopper, ruler, flat pan, cork stopper, large mixing bowl.

6. SAMPLING

6.1 Obtain at least 10 kg of the aggregate to be tested in accordance with ITM 207.

6.2 Reduce the sample to a $9,000 \pm 50$ g specimen in accordance with T248.

7. PREPARATION OF TEST SPECIMEN

7.1 DETERMINE MASS OF AIR DRIED SPECIMEN.

7.1.1 Measure and record the mass of the flat pan.

7.1.2 Transfer the specimen to the flat pan.

7.1.3 Air dry the specimen in accordance with T87.

7.1.4 Measure and record the mass of the flat pan and the air dried specimen (initial).

7.1.5 Calculate the mass of the air dried specimen (initial).

$$M_{si} = M_{ps} - M_p$$

Where:

M_{si} = mass of air dried specimen (initial) in g.

M_{ps} = mass of flat pan and air dried specimen (initial) in g.

M_p = mass of flat pan in g.

7.2 PREPARE PERMEAMETER

7.2.1 Place the permeameter on a hard, level, work surface adjacent to a sink.

7.2.2 Measure and record the inside diameter of the mold to the nearest 1 mm.

7.2.3 Place a rubber stopper in the drain hole of the mold from the underside. The rubber stopper shall not protrude into the mold so as to displace the bottom screen.

7.2.4 Place the bottom screen in the bottom of the mold to cover the drain hole.

7.2.5 Place the laboratory gravel in the bottom of the mold and ensure the bottom screen does not move.

7.2.6 Place the top screen over the laboratory gravel.

7.2.7 Compact and level the laboratory gravel by pushing down and rotating the top screen.

7.2.8 Measure and record the distance between the top of the mold and the top screen at the four quarter points around the circumference of the mold and in the center of the mold to the nearest 1 mm.

7.2.9 Calculate and record the average height between the top of the mold and the top screen.

$$H_{ba} = (H_{b1} + H_{b2} + H_{b3} + H_{b4} + H_{b5})/5$$

Where:

H_{ba} = average height between the top screen and the top of the mold in mm.

H_{b1} , H_{b2} , H_{b3} , H_{b4} = height at four quarter points around the circumference of the mold in mm.

H_{b5} = height at the center of the mold in mm.

7.2.10 Measure and mark the location of top screen on the outside of the mold.

7.2.11 Measure and record the mass of the mold with rubber stopper, bottom screen, pea gravel and top screen to the nearest 1 g.

7.3 PREPARE SPECIMEN

7.3.1 Place the specimen in a large mixing bowl.

7.3.2 Determine the amount of water required to make 9% moisture content.

$$M_{w9} = .09 \times M_{si}$$

Where:

M_{w9} = mass of water required in g.

M_{si} = mass of air dried specimen (initial) in g.

7.3.3 Add the required water to the specimen and mix thoroughly ensuring that the fines in the bottom of the bowl are wet.

7.4 LOAD THE SPECIMEN

7.4.1 Place the mold onto the vibrating table.

7.4.2 Place and level one third of the specimen in the mold using a scoop.

7.4.3 Place a cardboard cover on top of the specimen in the mold.

7.4.4 Place the lead weight on top of the cardboard cover.

7.4.5 Turn on the vibrating table.

7.4.6 Vibrate the specimen for two minutes while pushing down firmly and rotating the compaction weight with both hands.

7.4.7 Turn off the vibrating table.

7.4.8 Repeat 7.15 through 7.20 until the complete specimen is compacted in the mold.

7.4.9 Measure and record the mass of the mold with rubber stopper, bottom screen, pea gravel, top screen and specimen with 9% moisture to the nearest 1 g.

7.5 DETERMINE SPECIMEN PARAMETERS

7.5.1 Calculate the mass of the specimen with 9% moisture.

$$Ms_9 = Mms - Mm$$

Where:

Ms_9 = mass of the specimen with 9% moisture in g.

Mms = mass of the mold with rubber stopper, bottom screen, laboratory gravel, top screen and specimen with 9% moisture in g.

Mm = mass of the mold with rubber stopper, bottom screen, laboratory gravel and top screen in g.

7.5.2 Measure and record the distance between the top of the mold and the top of the specimen at the four quarter points around the perimeter of the mold and in the center of the mold to the nearest 1 mm.

7.5.3 Calculate and record the average height between the top of the mold and the top of the specimen.

$$Hta = (Ht1 + Ht2 + Ht3 + Ht4 + Ht5)/5$$

Where:

Hta = average height between top of the specimen and the top of the mold in mm.

$Ht1, Ht2, Ht3, Ht4$ = height at four quarter points around the circumference of the mold in mm.

$Ht5$ = height at the center in mm.

7.5.4 Calculate the cross sectional area of the specimen.

$$A_s = (3.14 \times L^2)/4$$

Where:

A_s = cross sectional area of the specimen in mm^2 .

L = diameter of the mold in mm.

7.5.5 Calculate the volume of the specimen in the mold.

$$V_s = (H_{ba} - H_{ta}) \times A_s$$

Where:

V_s = volume of the specimen in the mold in mm^3 .

H_{ba} = average height between the top screen and the top of the mold in mm.

H_{ta} = average height between top of the specimen and the top of the mold in mm.

A_s = cross sectional area of the specimen in mm^2 .

7.5.6 Calculate the density of the specimen with 9% moisture in the mold.

$$D_{s9} = C \times (M_{s9} / V_s)$$

Where:

D_{s9} = density of the specimen with 9% moisture in the mold in kg/m^3 .

M_{s9} = mass of the specimen with 9% moisture in the mold in g.

V_s = volume of the specimen with 9% moisture in the mold in mm^3 .

$C = 1,000,000$ = conversion factor from g/mm^3 to kg/m^3 .

8. PROCEDURE

8.1 Place the drain pan on the table adjacent to the sink.

8.2 Place the spacers in the drain pan. Note: The purpose of the spacers is to raise the bottom of the specimen to the same elevation as the outlet of the drain pan.

8.3 Remove the rubber stopper from the bottom of the mold.

8.4 Place the mold with bottom screen, laboratory gravel, top screen and specimen on the spacers in the drain pan.

8.5 Place the reservoir assembly on top of the mold and secure it in place using the locking ring.

8.6 Connect the tubes to the manometer outlets and affix them in a vertical position using the clamp and post

8.7 Connect the free end of the upper hose of the reservoir assembly to the faucet.

8.8 Place the free end of the lower hose of the reservoir assembly in the sink.

8.9 Place the deflector in the reservoir to disperse the flow of water preventing the formation of a vortex.

8.10 Turn on the water and begin filling the reservoir.

8.11 Open the valve in the lid and allow the air in the mold to escape.

8.12 Gently tap the sides of the mold using a hammer to help remove air trapped in the voids of the specimen.

8.13 Close the valve in the lid five minutes after the water begins flowing continuously through the valve.

8.14 Adjust the flow of water from the faucet to maintain the level in the reservoir at the mid-point of the outlet.

8.15 Place a piece of cork in the drain pan outlet to maintain the water level in the drain pan at the elevation of the bottom of the specimen as needed.

8.16 Allow the flow of water in the reservoir and drain pan to stabilize for 15 to 30 minutes to ensure the system reaches equilibrium.

8.17 Measure and record the head of water above the specimen.

8.18 Determine and record the mass of the dry collection bucket.

8.19 Place the collection bucket in the sink under the drain pan outlet.

8.20 Collect the runoff from the drain pan for one minute.

8.21 Determine and record the mass of the collection bucket with the runoff.

8.22 Calculate the mass of runoff collected from the drain pan in one minute.

$$Q = M_{br} - M_b$$

Where:

Q = mass of the runoff from drain pan in one minute in g.

M_{br} = mass of collection bucket with runoff in g.

M_b = mass of collection bucket in g.

8.23 Empty and dry the collection bucket.

8.24 Repeat steps 8.19 to 8.23 four more times to make a total of five iterations.

8.25 Calculate the average runoff collected from the drain pan in one minute.

$$Q_a = (Q_1 + Q_2 + Q_3 + Q_4 + Q_5)/5$$

Where:

Q_a = average runoff collected from the drain pan in one minute in g.

Q₁, Q₂, Q₃, Q₄, Q₅ = runoff collected from the drain pan in one minute in g.

8.26 Compare each runoff to the average runoff and note any difference larger than 10%. Replace any runoff more than 10% above or below the average with another runoff value collected over one minute. Calculate a new average.

8.27 Turn off the water and allow the permeameter to drain.

8.28 Measure and record the mass of the flat pan.

8.29 Transfer the drained specimen to the flat pan using a scoop.

8.30 Measure and record the mass of the flat pan with the drained specimen.

8.31 Calculate the mass of the drained specimen.

$$M_{sd} = M_{pd} - M_p$$

Where:

M_{sd} = mass of the drained specimen in g.

M_{pd} = mass of the flat pan and drained specimen in g.

M_p = mass of the flat pan.

8.32 Oven dry the drained specimen in a flat pan accordance with T265.

8.33 Measure and record the mass of the flat pan and oven dried specimen (final).

8.34 Calculate the mass of the oven dried specimen (final).

$$M_{sf} = M_{psf} - M_p$$

Where:

M_{sf} = mass of oven dried specimen (final) in g.

M_{psf} = mass of flat pan and air dried specimen (final) in g.

M_p = mass of the flat pan in g.

8.35 Calculate the mass of water in the drained specimen.

$$M_{wd} = M_{pd} - M_{psf}$$

Where:

M_{wd} = mass of water in the drained specimen in g.

M_{pd} = mass of flat pan and drained specimen in g.

M_{psf} = mass of the flat pan and oven dried specimen (final) in g.

8.36 Calculate the moisture content of the drained specimen to the nearest 0.1%.

$$W = 100\% \times (M_{wd} / M_{sf})$$

Where:

W = moisture content of the drained specimen in %

M_{wd} = mass of water in the drained specimen in g.

M_{sf} = mass of oven dried specimen (final) in g.

8.37 Calculate the material loss from the specimen during the test.

$$M_{sl} = M_{si} - M_{sf}$$

Where:

M_{sl} = mass of specimen lost during the test in g.

M_{si} = mass of air dried specimen (initial) before the test in g.

M_{sf} = mass of air dried specimen (final) after the test in g.

8.38 Calculate the wet density of the drained specimen.

$$D_{sd} = C \times (M_{sd} / V_s)$$

Where:

D_{sd} = wet density of the drained specimen in kg/m^3 .

M_{sd} = mass of the drained specimen in g.

V_s = volume of the specimen in the mold in mm^3 .

$C = 1,000,000$ = conversion factor from g/mm^3 to kg/m^3 .

8.39 Calculate the permeability of the specimen.

$$K = Q_a \times (H_{ba} - H_{ta}) / (T \times A_s \times H_w)$$

Where:

K = permeability of the specimen in m/sec.

Q_a = average runoff collected from the drain pan for the actual time in g.

H_{ba} = average height between the top screen and the top of the mold in mm.

H_{ta} = average height between top of the specimen and the top of the mold in mm.

T = time over which a runoff sample is collected, typically 60 seconds.

A_s = cross sectional area of the specimen in mm^2 .

H_w = head of water above the specimen in mm.

10. REPORT

10.1 Report the permeability of the specimen using the attached report form.

Subject: Worksheet for Permeability of Aggregates							
Mass Air Dry Specimen Initial				Average Runoff in One Minute			
Mass Flat Pan (g)				Mass of Bucket (g)			
Mass Pan & Dry Specimen (g)				Mass Bucket & Runoff #1 (g)			
Mass Dry Specimen (g)				Mass Runoff #1 (g)			
				Mass Runoff & Runoff #2 (g)			
Height Top of Screen to Top of Mold				Mass Runoff #2 (g)			
Height #1 (mm)				Mass Bucket & Runoff #3 (g)			
Height #2 (mm)				Mass Runoff #3 (g)			
Height #3 (mm)				Mass Bucket & Runoff #4 (g)			
Height #4 (mm)				Mass Runoff #4 (g)			
Height #5 (mm)				Mass Bucket & Runoff #5 (g)			
Average Height (mm)				Mass Runoff #5 (g)			
				Average Runoff (g)			
Mass of Water for 9% Moisture							
Mass of Dry Specimen (g)				Mass of Drained Specimen			
Mass of 9% of Dry Specimen (g)				Mass Flat Pan (g)			
				Mass Pan & Drained Specimen (g)			
Mass of Compacted Specimen with 9% Moisture				Mass Drained Specimen (g)			
Mass of Mold & Moist Specimen (g)							
Mass of Mold (g)				Mass of Air Dry Specimen Final			
Mass of Moist Specimen (g)				Mass Flat Pan (g)			
				Mass Pan and Dry Specimen (g)			
Height Top of Moist Specimen to Top of Mold				Mass Dry Specimen (g)			
Height #1 (mm)							
Height #2 (mm)				Mass of Water in Drained Specimen			
Height #3 (mm)				Mass Pan & Drained Specimen (g)			
Height #4 (mm)				Mass Pan & Dry Specimen (g)			
Height 35 (mm)				Mass water in Drained Specimen (g)			
Average Height (mm)							
				Moisture Content of Drained Specimen			
Area of Moist Specimen				Mass Water Drained Specimen (g)			
Diameter of the Mold (mm)				Mass Air Dried Specimen (g)			
Area of Moist Specimen (mm ²)				Moisture Content Drained Specimen %			
Volume of Moist Specimen				Material Lost During Test			
Average Height of Screen (mm)				Mass Dry Specimen Initial (g)			
Average Height from Specimen (mm)				Mass Dry Specimen Final (g)			
Area of Moist Specimen (mm ²)				Mass Material Lost (g)			
Volume of Moist Specimen (mm ³)							
				Wet Density of Drained Specimen			
Density of Moist Specimen				Mass Drained Specimen (g)			
Mass of Moist Specimen (g)				Volume of Moist Specimen (mm ³)			
Volume of Moist Specimen (mm ³)				Wet Density of Specimen (kg/m ³)			
Density of Moist Specimen (kg/m ³)							
				Permeability of Specimen			
				Average Runoff (g)			
				Time Runoff Collected (s)			
				Area of Specimen in (mm ²)			
				Head of Water (mm)			
				Permeability of Specimen (m/s)			